




## Perfect for Auger Drilling and Screw Anchor Installations


When accuracy is key, The **Auger Torque Alignment Monitor** is an essential tool for ensuring your application is precise and quick.

Unrestricted by parent machine size, the Alignment Monitor is easy to install with your existing equipment. Now the operator can see the alignment from all angles, there's no need for additional operatives to watch over the installation.


**A one man operation with accurate, fast and cost effective results.**



Application is aligned



Application is moving out of alignment



Application is out of alignment

Visit the Auger Torque website to watch a demo

**[www.augertorqueusa.com](http://www.augertorqueusa.com)**

CALL +1 844 287 6300

EMAIL [sales@augertorqueusa.com](mailto:sales@augertorqueusa.com)

OR CONTACT YOUR NEAREST DEALER

rev 1